



# Wide Right Footplate Template

Securely tape this template to the right footplate.

Ensure that it does not shift while the holes are drilled.



Copyright ©2019 LUCI, All Rights Reserved.

P002-016 Version 3.0

All product names, brands, and trademarks are property of their respective owners. All company, product, and service names used in this website are for identification purposes only. Use of these names, trademarks, and brands does not imply endorsement.

For more information visit [luci.com/patents](http://luci.com/patents).