



Tear this template along the perforated lines. Line up the appropriate green edge with the slot in the footplate. Securely tape this template to the footplate. Ensure that it does not shift while the holes are drilled.

Copyright ©2022 LUCI

P002-053 Version 1.0

All Rights Reserved.

All product names, brands, and trademarks are property of their respective owners. All company, product, and service names used in this website are for identification purposes only. Use of these names, trademarks, and brands does not imply endorsement.

For more information visit: luci.com/patents.